

The perfect way to reproduce of MONO vinyl record


INTRODUCTION

Thank you for purchasing the 「華」SL MONO cartridge. If you play a mono record with a stereo cartridge, imperfections such as crosstalk, noise, phase errors, tracking error, antiskating and distortion due to the difference between the left/right channels will result in an unstable and partially fuzzy image.

A mono switch to some extent can improve this, however, a mono cartridge is the only way to get the best sound from a mono record.


The SL MONO Shibata design diamond needle profile will ensure you get the best possible detail and accuracy from your mono records.

Color and polarity of「華」SL-MONO output terminal pins



Option 1

Wire cartridge as for stereo reproduction, illustrated below. Channel 1. Red +(positive) and Green – (negative) Channel 2. White +(positive) and Blue – (negative)




Option 2

This option works for phono amplifiers with a Left/Right channel selection switch.



Option 3

Use this option if one loudspeaker is used and you have a mono amplifier, or left/right balance control on your stereo amplifier. Turn fully to the one channel used.



華 SL MONO Specification

| Stylus | Nude Diamond Shibata |
|--------------------------|----------------------|
| Stylus Shape | 0.27x1.57mil |
| Cantilever | Aluminum |
| Output level | 0.4mv/1KHz |
| Vertical Tracking force | 2gr |
| Trackability | 70 μ m/2gr |
| Frequency response | 15-32,000Hz |
| Impedance | 23Ω/1KHz |
| Suggested load Impedance | >200Ω |
| Cartridge weight | 5gr |
| Body Color | Black |

